

Cisco Configuration Essentials

Campus Network Design & Operations Workshop



These materials are licensed under the Creative Commons Attribution-NonCommercial 4.0 International license
(<http://creativecommons.org/licenses/by-nc/4.0/>)



UNIVERSITY OF OREGON

Last updated 24th October 2022



Introduction to Cisco devices

- Presentation describes components of Cisco routers and switches running Cisco IOS
 - IOS is Cisco's Internet Operating System, the software used to control the router or switch
- Cisco produces other equipment running other operating systems:
 - IOS-XR (high end routers)
 - IOS-XE (replacing IOS)
 - NX-OS (datacentre & enterprise switches)
- Equipment from other vendors uses similar concepts

Where is the configuration?

Router always has two configurations

- **running-config**

- Stored in RAM
- Shows which parameters are currently in use.

```
show running-config
```

- Modified with:

```
configure terminal
```

- **startup-config**

- Stored in NVRAM
- Loaded by router next time it boots
- This is where the running-config is saved

```
show startup-config
```



UNIVERSITY OF OREGON

Management input sources

- Console:
 - Direct access via serial port
- Auxiliary Port:
 - Access via Modem or other serial devices
 - (Also used for accessing other serial devices)
- Virtual Terminals (VTY):
 - Telnet/SSH

Changing the configuration

- Commands are implemented immediately
 - Be careful when typing at the command line interface
- When working on the serial console or via Telnet or SSH, commands can also be:
 - Copied from a text file and pasted into the terminal
 - Be very careful with cut and paste – character loss from cut and paste buffer can cause unintended consequences
 - Copied by SCP or TFTP from a file prepared previously on a SCP or TFTP server
 - Strongly encouraged in day-to-day operations

Access Modes

- Standard user access:
 - Allows users to see some of the device status
 - Prompt:

```
Router>
```

- Privileged user access:
 - Full administrative view of the device
 - Accessed by:

```
Router> enable
Router#
```

- Configuration mode:
 - Accessed by:

```
Router# configure terminal
Router(config)#
```

Access Modes

- Exiting configuration mode:

```
Router(config)# end      (or Ctrl-Z)  
Router#
```

- Exiting privileged mode:

```
Router# disable  
Router>
```

- Logging off:

```
Router> exit
```

Saving Configuration

- Very important to save the configuration to the device NVRAM after it has been updated

- The device does NOT do it automatically
 - Done in privileged mode:

```
Router# write memory
```

- Can be shortened to just:

```
Router# wr
```

- Full long hand form of Cisco command to save configuration:

```
Router# copy running-config startup-config
```

Saving Configuration

- There are many available options for saving the configuration:
 - Locally on the device
 - On an external server using TFTP or SCP

```
Router# copy running-config ?
  flash:          Copy to flash: file system
  ftp:           Copy to ftp: file system
  scp:           Copy to scp: file system
  slot0:          Copy to slot0: file system
  slot1:          Copy to slot1: file system
  startup-config  Copy to startup configuration
  tftp:           Copy to tftp: file system
  ...
  ...
```

Context Help

- Use “?” to obtain a list of commands available in your current configuration mode:

```
Router(config) #?
Configure commands:
  aaa                      Authentication, Authorization and Accounting
  aal2-profile              Configure AAL2 profile
  access-list                Add an access list entry
  alarm-interface            Configure a specific Alarm Interface Card
  alias                     Create command alias
  appfw                     Configure the Application Firewall policy
  application                Define application
  archive                   Archive the configuration
  arp                       Set a static ARP entry
```

Online Help

- Use “?” also to see all possible parameters to an incomplete command:

```
Router(config)#username ?
  WORD  User name
Router(config)#username cndlabs ?
  password      Specify the password for the user
Router(config)#username cndlabs password secret-pass

Router#show ?
  aaa                      Show AAA values
  aal2                     Show commands for AAL2
  access-expression         List access expression
  access-lists              List access lists
  accounting                Accounting data for active sessions
```

Command Completion

- Use the Tab key to complete a command:

```
router(config)# int<TAB>
router(config)# interface fa<TAB>
router(config)# interface fastEthernet 0
router(config-if)# ip add<TAB>
router(config-if)# ip address n.n.n.n m.m.m.m
```

Command Shorthand

- IOS understands shorthand
 - Complete command does not need to be typed as long as the initial characters are unique

```
router(config)# int fa 0
router(config-if)# ip add 192.168.1.1 255.255.255.0
router(config-if)# no sh
router(config-if)# ^Z
router# sh ip int br
Interface      IP-Address      OK?    Method   Status  Protocol
FastEthernet0  192.168.1.1    YES    NVRAM    up      up
```

- Can you work out the full form of the above commands?

Moving faster around the command line

Move within command history



Previous command



Next command

Line editing



move to the left within a line



move to the right within a line

Ctrl-a

move to beginning of line

Ctrl-e

move to end of line

Ctrl-k

delete until end of line

Verifying and Troubleshooting

- Checking configuration:
 - Need to be in privileged mode to do this:
 - Current running configuration

```
Router# show running-config
```

- Saved configuration

```
Router# show startup-config
```

- Or

```
Router# show configuration
```

- Checking specific interface running configuration

```
Router# show run interface Gig0/0
```

Verifying and Troubleshooting

- Checking interface status:
 - Can be in standard or privileged mode to do this:

```
Router# show interface Gig0/0
```

- Checks interface Gigabit 0/0

- Checking status of all interfaces:
 - Can be in standard or privileged mode to do this:

```
Router# show interface description
Interface  Status      Protocol Description
Fa0/0      up          up          Backbone LAN
Fa0/1      up          up          Server LAN
Fa1/0      up          up          Wireless LAN
Fa1/1      up          up          ISP Link
Lo0        up          up          Loopback
```

Verifying and Troubleshooting

- Getting a brief list of IPv4 status of all interfaces

```
Router# show ip interface brief
```

- Getting a brief list of IPv6 status of all interfaces

```
Router# show ipv6 interface brief
```

- Find out about directly attached Cisco devices

- “Cisco Discovery Protocol” – CDP

- Can be in standard or privileged mode to do this:

```
Router# show cdp neighbor
```

Verifying and Troubleshooting

- Checking logs:
 - Need to be privileged mode to do this:

```
Router# show logging
```

- Show software and hardware details of the device:

```
Router# show version
```

- Or:

```
Router# show hardware
```

- Show device inventory (more hardware details)

```
Router# show inventory
```

Verifying and Troubleshooting

Checking device status while inside configuration mode:

```
Router(config)# do show interface Gig0/0
```

- The “do” command lets the operator run all privileged mode commands from within the configuration mode of the router
- Much quicker/easier than exiting configure mode, running the status command, and then returning to configure mode

Undoing Configuration

To undo IOS configuration:

- Simply negate the configuration command

```
Router# sh run int fa 0/0
interface FastEthernet 0/0
  description Link to Core-Router
  ip address 192.168.1.10 255.255.255.224

Router# conf t
Router(config)# int fa 0/0
Router(config-if)# no ip address
Router(config-if)# end

Router# sh run int fa 0/0
interface FastEthernet 0/0
  description Link to Core-Router
Router#
```

Poor defaults

For historical reasons, there are some legacy default settings which you will want to change on every device

Poor defaults (1)

- Log messages are sent to the console port
 - They mix in with whatever you are typing!

```
Router(config-if)#ip addre*Jun 20 07:53:55.755:  
%LINEPROTO-5-UPDOWN: Line protocol on Interface  
GigabitEthernet3/0, changed state to downss 1.2.3.4
```

- Solution: log to memory buffer instead

```
Router(config)#no logging console  
Router(config)#logging buffer 8192 debug
```

- Use “show log” to see buffer contents

Poor defaults (2)

- DNS lookups are sent to broadcast address
 - Can cause long delays e.g. for reverse lookups

```
Router#ping nsrc.org
Translating "nsrc.org"...domain server (255.255.255.255)
% Unrecognized host or address, or protocol not running.
```

- Solution: disable DNS resolution completely

```
Router(config) #no ip domain-lookup
```

- Alternatively: configure real DNS servers
 - But this can also lead to delays when network is down

```
Router(config) #ip name-server 8.8.8.8
Router(config) #ip name-server 8.8.4.4
```

Poor defaults (3)

- Typos interpreted as hostname to connect to

```
Router#wrtie
Translating "wrtie"...domain server (255.255.255.255)

% Bad IP address or host name
```

- Solution: “transport preferred none”

```
Router(config)#line con 0
Router(config-line)#transport preferred none
Router(config-line)#line vty 0 4
Router(config-line)#transport preferred none
```

```
Router#wrtie
^
% Invalid input detected at '^' marker.
```

* line vty 0 15 on some devices

Poor defaults (4)

- Router does not forward IPv6 traffic!
- Solution:
 - only on routers, not layer2-only devices

```
Router (config) #ipv6 unicast-routing
```

Questions?