

Layer 3 Switches

Campus Network Design & Operations Workshop



These materials are licensed under the Creative Commons Attribution-NonCommercial 4.0 International license
(<http://creativecommons.org/licenses/by-nc/4.0/>)



UNIVERSITY OF OREGON


Last updated 25th October 2022



What's a Layer 3 switch?


- It's an Ethernet switch!
 - Can look at Ethernet headers
 - Builds MAC address table
- And it's a router!
 - Can look at IP headers
 - Has IP forwarding table and ARP table
- Which function it performs depend on how you configure it
- Out-of-the-box it will default to a simple L2 Ethernet switch

Factory Default



```
vlan 1
!
interface range Gi 1 - 8
  no shutdown
  switchport
  switchport mode access
  switchport access vlan 1
!
```

VLANs




```
vlan 10,20
```

```
interface range Gi 1 - 4
  switchport mode access
  switchport access vlan 10
```

```
interface range Gi 5 - 8
  switchport mode access
  switchport access vlan 20
```

Question: how does the device behave differently after this config change?

VLAN trunking




Question: what is different about the frames on this wire?



UNIVERSITY OF OREGON

Management IP address



```
vlan 1
```

```
  interface range Gi 1 - 8
    switchport access vlan 1
```

```
interface Vlan1
```

```
  ip address 192.168.1.1 255.255.255.0
```

```
  ip default-gateway 192.168.1.254
```

```
  ! or: ip route 0.0.0.0 0.0.0.0 192.168.1.254
```


The Management Interface

- The switch has its own IP interface on VLAN 1, with its own IP address
- Imagine the switch's CPU is plugged into VLAN 1 (but without using up a physical port)
- You use this to manage the switch (ssh, snmp)
- Like any other IP device, it needs a default gateway to be able to send packets to a destination address on a different subnet

IP routing

- Extend this by giving the switch an IP address on multiple VLANs
 - Each address is of course within the IP subnet for that particular VLAN
- Enable the internal router within the switch
- It can receive datagrams on one VLAN, and resend them on another
- You have a layer 3 switch!

IP routing



```
vlan 10,20
ip routing


interface Vlan10
  ip address 192.168.1.1 255.255.255.0
interface Vlan20
  ip address 192.168.2.1 255.255.255.0

ip route 0.0.0.0 0.0.0.0 192.168.1.254
```


Routed VLAN interfaces

- It's really that simple!
- We have an IP address on each VLAN
- Other devices can point their default gateway at us
- We will forward datagrams on their behalf
 - Based on our IP forwarding table
 - Connected routes, static routes etc.

Acting as a gateway




IPv6 is the same



```
ipv6 unicast-routing
!
interface Vlan10
    ipv6 address 2001:db8:0:10::1/64
interface Vlan20
    ipv6 address 2001:db8:0:20::1/64
!
ipv6 route ::/0 2001:db8:0:10::ff
```

Simple campus: 1 subnet/building




```
interface Gi1
  switchport mode access
  switchport access vlan 10
```

```
interface Vlan10
  ip address 192.168.1.1 255.255.255.0
```

```
interface Gi2
  switchport mode access
  switchport access vlan 20
```

```
interface Vlan20
  ip address 192.168.2.1 255.255.255.0
```

Multiple subnets per building



```
interface Gi1
  switchport mode trunk
  switchport trunk allowed vlan 10-12

interface Vlan10
  ip address 10.1.0.1 255.255.255.0
interface Vlan11
  ip address 10.1.1.1 255.255.255.0
interface Vlan12
  ip address 10.1.2.1 255.255.255.0
```

```
interface Gi2
  switchport mode trunk
  switchport trunk allowed vlan 20-22

interface Vlan20
  ip address 10.2.0.1 255.255.255.0
interface Vlan21
  ip address 10.2.1.1 255.255.255.0
interface Vlan22
  ip address 10.2.2.1 255.255.255.0
```



UNIVERSITY OF OREGON

Question: what has to be different at the building aggregation switch?



Hints and tips

- Remember, one subnet = one VLAN
- Don't use VLAN 1
 - It's the “default VLAN” and often has special default behavior
 - It may appear by default on all ports
 - It's often hard to use with tagging
 - Better to ignore it or remove it completely (if possible)
 - In general, VLANs 2 to 4094 are usable
 - some vendors reserve some for special purposes: check the documentation


Hints and tips

- Don't enable the same VLAN on links to different buildings!
 - A layer 3 switch lets you do this but that doesn't mean it's a good idea.
“VLAN spaghetti”
- Implies: a management VLAN per building, a wired VLAN per building, a WiFi VLAN per building etc
- Choose a consistent scheme
 - e.g. VLAN 2-9 for core, VLAN 10-19 for building 1, VLAN 20-29 for building 2 etc.

Routed interfaces / subinterfaces

- Some layer 3 switches let you configure “routed ports”
 - This makes it work exactly like a router instead of a switch
- Some also support routed **sub-interfaces** with VLAN tags
 - This means you can route multiple subnets to each building, without having to create any actual VLANs
 - You can re-use the *same* VLAN tags for *different subnets in different buildings!*
 - Makes the distribution/edge switch configs almost identical everywhere
- Routed ports don't participate in STP, so each building becomes its own independent spanning tree domain

Fully routed interfaces



```
interface Gi1
  no switchport

interface Gi1.10
  encapsulation dot1q 10
  ip address 10.1.0.1 255.255.255.0

interface Gi1.11
  encapsulation dot1q 11
  ip address 10.1.1.1 255.255.255.0
```

```
interface Gi2
  no switchport

interface Gi2.10
  encapsulation dot1q 10
  ip address 10.2.0.1 255.255.255.0

interface Gi2.11
  encapsulation dot1q 11
  ip address 10.2.1.1 255.255.255.0
```

*Both buildings use VLAN tags 10-11 but
these are different, isolated subnets*

Questions?